



Before you begin building, look over the instructions carefully and test fit parts without cementing. Remove small parts from 'runners' with a modeler's knife, do not twist them off.

MPC kits are made of the highest quality styrene plastic.

Use only paint and cement made for styrene. Be sure that cement is used sparingly.

Trim off excess plastic or 'flash' and scrape plating

from chromed parts before joining.
Follow the instructions carefully. The parts are numbered in their assembly order.





**Body Color** 











