## DODGE DART

## **IMPORTANT! READ THIS FIRST**

You may build this kit more than one way. Before you begin building, look over the instructions carefully. Following the procedure given, test-fit parts together without cementing, after you haved decided what version to build. This way you will be more familiar with the location of parts when it becomes time to use cement.

For removing small parts from the "runners" it is best to use a modeler's knife. Do not attempt to "twist" them off.

The highest quality styrene plastic goes into the making of each MPC model. Only paint and cement

PLATED PARTS

non-chromed accessories to the body and paint the whole unit at one time. You should have no trouble assembling your kit if the instructions are followed properly.

made for styrene should be used. Before joining parts, trim off excess plastic or "flash." Scrape

plating from chromed parts where they are to be

ioined to other parts. Be careful not to get cement

on exposed areas. To join parts use cement sparingly. Apply cement to small parts with a toothpick.

When painting your model it is best to cement all



GOOD

DO NOT 7 PART NUMBERS −−−→ CEMENT **—**—→ CEMENT

**mpc** 

Dodge and related logos, vehicle model names and trade dresses are trademarks of FCA US LLC and used under license by Round2 LLC. © 2020 FCA US LLC. Goodyear (and winged foot design) and Blimp are trademarks of The Goodyear Tire & Rubber Company used under license by Round 2, LLC, South Bend, IN 46628. Copyright 2020 The Goodyear Tire & Rubber Company. MPC and ROUND 2 and design are trademarks of Round 2, LLC. ©2020 Round 2, LLC, South Bend, IN 46628 USA. Product and packaging designed in the USA. Made in China. All rights reserved.





